

### EPA Certified Propane Conversion Kits

(most in-demand kits for fleet operators)

<u>Make</u>	<u>Model</u>	<u>Year</u>	<u>Engine</u>	<u>Fuel Type</u>	
FORD	E150	2009	5.4L	BI-FUEL	Wagon
		2009-2010	4.6L & 5.4L	BI-FUEL	Econoline
		2010-2011	4.6L & 5.4L	BI-FUEL	Wagon
		2009-2011	4.6L & 5.4L	BI-FUEL	Van
	E250	2009	5.4 L	BI-FUEL	Van
		2010	4.6L & 5.4L	BI-FUEL	Van/Cutaway
		2011	4.6L & 5.4L	BI-FUEL	Van/Cutaway
	E350	2009	5.4L	BI-FUEL	Wagon/Cutaway
		2010	4.6L & 5.4L	BI-FUEL	Van/Cutaway/Wagon
		2010	6.8L	BI-FUEL	
		2011	4.6L & 5.4L	BI-FUEL	Van/Cutaway/Wagon
	E450	2010	6.8L	BI-FUEL	
		2011	6.8L	BI-FUEL	
	F150	2009	5.4L	BI-FUEL	
		2010	5.4L	BI-FUEL	
		2012	5.0L	BI-FUEL	
	Crown Vic	2008-2011	4.6L	BI-FUEL	
	E250	2009 - 2011	5.4L	DEDICATED	
		2010	5.4L	DEDICATED	Econoline Van
	E350	2009-2011	5.4L	DEDICATED	
		2010	5.4L	DEDICATED	Econoline Van
	E450	2009-2010	6.8L	DEDICATED	Cutaway
		2011	6.8L	DEDICATED	
		2010-2011	6.8L	DEDICATED	DRW Cutaway
	Police Inter	2007-2012	4.6L	DEDICATED	
	F150	2007-2008	5.4L	DEDICATED	
	F250	2008-2010	5.4L	DEDICATED	
F350	2009-2010	5.4L	DEDICATED		
GM	Impala	2009	3.5L - 3.9L	BI-FUEL	
		2009	3.5L - 3.9L	BI-FUEL	E85
		2010	3.5L	BI-FUEL	
	Silverado HD	2008-2012	6.0L	BI-FUEL	
	Silverado	2009-2012	5.3L	BI-FUEL	
	Sierra	2009-2012	5.3L	BI-FUEL	
	Sierra HD	2009-2012	6.0L	BI-FUEL	
	Suburban	2009-2010	5.3L	BI-FUEL	
	Tahoe	2009-2012	5.3L	BI-FUEL	
	Yukon	2010-2011	5.3L	BI-FUEL	
	Express Van	2009 & 2011	5.3L-6.0L	BI-FUEL	
	Savanah	2009	4.8L - 6.0L	BI-FUEL	
		2011	5.3L	BI-FUEL	
	HD2500	2009-2011	6.0L	BI-FUEL	
	G3500	2010	6.0L	BI-FUEL	Cutaway
	G4500	2010	6.0L	BI-FUEL	Cutaway
	Workhorse	2010	6.0L	BI-FUEL	
	C2500	2010	6.0L	BI-FUEL	Van /Pickup
	C3500	2010	6.0L	BI-FUEL	Van /Pickup
	C4500	2010	8.1L	DEDICATED	Truck/Shuttle
C550	2010	8.1L	DEDICATED	Truck/Shuttle	